

DISC SUPPORT

CDDA	✓
MP3	✓
WMA	✓
AAC	✓
JPEG	✓
DVD (AUDIO & VIDEO)	✓

MUSIC FILE FORMATS

WAV	
MP3	✓
WMA	✓
WMA 10 PRO WITH VBR	
AAC AUDIO (.AAC OR .MP4)	✓
AAC AUDIO (.AAC, .MP4, OR M4B)	

DEVICE CONNECTION

Audio Jack Connection for Portable Music Players	✓
SD Connection	
Bluetooth Streaming Audio	○ via HFM
Charging via USB port on Radio	✓
USB Stick - Play Music via USB direct connect to Radio	✓

MUSIC CONTROL

SD Card Music Playback with Voice Control by Song/Artist Name	
iPod/USB Playback with radio control	○ via HFM USB port
VR Play commands (Play artist..., Play genre..., Play playlist)	○ via HFM USB port
USB Stick - Basic Voice Control of Playback via port direct connect to Radio	
USB Stick - Voice Control by Song/Artist Name via USB Port on Radio	

STORAGE

SD / USB supported File Size	32 GB
Hard Disk Total Space (GB)	40
Music Storage Space (apx GB)	28
Approximate HD Song Capacity	6.700

SONG INFORMATION

Music copy via CD/USB	CD/USB port on radio
Gracenote Music ID	✓