

DISC SUPPORT

CDDA	✓
MP3	✓
WMA	✓
AAC	
JPEG	
DVD (AUDIO & VIDEO)	

MUSIC FILE FORMATS

WAV	✓
MP3	✓
WMA	✓
WMA 10 PRO WITH VBR	✓
AAC AUDIO (.AAC OR .MP4)	
AAC AUDIO (.AAC, .MP4, OR M4B)	✓

DEVICE CONNECTION

Audio Jack Connection for Portable Music Players	✓
SD Connection	✓
Bluetooth Streaming Audio	✓
Charging via USB port on Radio	✓
USB Stick - Play Music via USB direct connect to Radio	✓

MUSIC CONTROL

SD Card Music Playback with Voice Control by Song/Artist Name	✓
iPod/USB Playback with radio control	✓
VR Play commands (Play artist..., Play genre..., Play playlist)	✓
USB Stick - Basic Voice Control of Playback via port direct connect to Radio	✓
USB Stick - Voice Control by Song/Artist Name via USB Port on Radio	✓

STORAGE

SD / USB supported File Size	32 GB
Hard Disk Total Space (GB)	
Music Storage Space (apx GB)	
Approximate HD Song Capacity	

SONG INFORMATION

Music copy via CD/USB	
Gracenote Music ID	